

## Wireless safety edge set up (can use 1.5V OR 3.6V lithium batteries)

Insert the 2 x batteries supplied into the bottom slat transmitter

Wire your optical eyes into the bottom slat transmitter as shown in the image. **Green – 4** **Brown – 5** **White - 6**

Press the RED button on the radio card for 2 seconds

Now press the white button on the OUTSIDE of bottom slat transmitter for 2 seconds

The BLUE LED on your radio card will be flashing – this means your safety edge is now programmed in!

**\*IMPORTANT\***

**MAKE SURE THE DIP SWITCH UNDER THE TERMINAL BLOCK IS SET TO WHAT BATTERY TYPE YOU ARE USING – 1.5v OR 3.6v**

